

# Series <sup>10-</sup>ARP20 to <sup>10-</sup>ARP40 Direct Operated Precision Regulator Direct Operated Precision Regulator Series <sup>10-</sup>ARP20K to <sup>10-</sup>ARP40K Direct Operated Precision Regulator with Backflow Function

• Clean room compliant (10-ARP).

- RoHS
- Clean room compliant, copper-free, fluorine-free, silicone-free (21-ARP).
- With the backflow function it incorporates a mechanism to exhaust the air pressure in the outlet side reliably and quickly.







ously.) Note 4) The only difference from the standard specifications is the pressure regulator

spring. It does not restrict the setting of 0.2 MPa/0.6 MPa or more.

c

d

е

f

-standard

Semi

6

When the pressure gauge is attached, a 0.2 MPa pressure gauge for 0.2 MPa setting will be fitted, and a 0.7 MPa pressure gauge for 0.6 MPa setting will be fitted

Note 6) For options: E1, E2, E3, E4. This product is for overseas use only according to the new Measurement Law. (The SI unit is provided for use in Japan.) Note 7) O : For thread type, NPT only.

Note 8) △ : Combination available for options : E1, E2, E3, E4.

Flow Control Equipment



### Specifications

	Model		10-ARP20 (K)	10-ARP30 (K)	10-ARP40 (K)			
Port size			1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2			
Fluid				Air	Air			
Proof pressure				1.2 MPa				
Maximum operati	ng pressure			0.7 MPa				
	0.4 MPa setting	(Ex.)10-ARP30-02BG		0.005 to 0.4 MPa				
Set pressure range Note1)	0.2 MPa setting	(Ex.)10-ARP30-02BG-1	0.005 to 0.2 MPa					
	0.6 MPa setting	(Ex.)10-ARP30-02BG-3	0.008 to 0.6 MPa					
Setting sensitivity			Within 0.2% F.S.					
Repeatability Note 2	)		Within ±1% F.S. (or ±3 kPa)					
	0.4 MPa setting	(Ex.)10-ARP30-02BG	1 L/min [ANR] or less (at P2 = 0.4 MPa)					
Air consumption	0.2 MPa setting	(Ex.)10-ARP30-02BG-1	0.6 L/min [ANR] or less (at P2 = 0.2 MPa)					
	0.6 MPa setting	(Ex.)10-ARP30-02BG-3	1.4 L/min [ANR] or less (at P2 = 0.6 MPa)					
Pressure gauge p	ort size		1/8	1/8	1/4			
Amelainet and fluid			-5 to 60°C (No freezing)					
Ambient and fluid temperature With a digital pressure switch (Ex.)10-ARP30-02BE1			–5 to 50°C (No freezing)					
Construction			Bleed type					
Weight (kg) Note 3)			0.2	0.3	0.5			

Note 1) When a product with backflow function (10-ARP20K to 40K) is chosen, set the inlet pressure 0.05 MPa or higher than the set pressure.

Note 2) For the type set to 0.2 MPa only, repeatability will be within ±3 kPa.

Note 3) Mass shown is for product without any options.

### **Optional Parts**

### Clean Room Compliant (10-)

		Model	10-ARP20(K)	10-ARP40(K)			
Bracket assembly Note 1)			ARP20P-270AS	ARP30P-270AS	ARP40P-270AS		
Set nut			AR23P-260S	AR33P-260S	AR43P-260S		
	0.4 MPa		G49-4-□01				
	0.2 MPa	Round type Note 2)	G49-2	G49-2-□02			
_	0.7 MPa		G49-7	G49-7-□02			
Pressure gauge Digi		NPN output / Wiring bottom entry	ISE35-N-25-MLA [ISE35-N-25-M (Switch body only)]				
	Digital type	NPN output / Wiring top entry	ISE35-R-25-MLA [ISE35-R-25-M (Switch body only)]				
	Digital type	PNP output / Wiring bottom entry	ISE35-N-65-MLA [ISE35-N-65-M (Switch body only)]				
		PNP output / Wiring top entry	ISE35-R-65-	n body only)]			

### Copper, Fluorine and Silicone-free + Low Particle Generation (21-)

Model			21-ARP20(K)	21-ARP30(K)	21-ARP40(K)
Bracket assembly Note 1)		ARP20P-270AS	ARP30P-270AS	ARP40P-270AS	
Set nut		AR23P-260S	AR33P-260S	AR43P-260S	
	0.4 MPa		G49-4-🗆	01MS-X3	G49-4-□02MS-X3
Pressure gauge	0.2 MPa	Round type Note 2)	G49-2-□	G49-2-□02MS-X3	
0.7 MPa			G49-7-□01MS-X3		G49-7-□02MS-X3


Note 1) Assembly includes a bracket and set nuts.

Note 2) 
 Din part numbers for a round-type pressure gauge indicates a type of connection thread. No indication is necessary for R; however, indicate N for NPT. The G thread is unavailable. If it is required, select the R thread type (NII) instead. Please contact SMC regarding the pressure gauge supply for psi unit specifications. Note 3). Lead wire with connector (2 m), adapter, lock pin, C-ring (1 pc.), and mounting screws (2 pc.) are included. [] 5:With body only.

For how to order the digital pressure switch, refer to the following specific page for the digital pressure switch.




### Direct Operated Precision Regulator Series <sup>10</sup>/<sub>21</sub>- ARP20 to <sup>10</sup>/<sub>21</sub>- ARP40 Direct Operated Precision Regulator with Backflow Function Series <sup>10</sup>/<sub>21</sub>- ARP20K to <sup>10</sup>/<sub>21</sub>- ARP40K



### Direct Operated Precision Regulator Series 21-ARP20 to 21-ARP40 Direct Operated Precision Regulator with Backflow Function Series 21-ARP20K to 21-ARP40K

### Dimensions



### **Pressure Gauge Option**

Option	Digital pressure switch	Digital pressure switch	Round type
	(Electrical entry: Wiring bottom entry)	(Electrical entry: Wiring top entry)	pressure gauge
Dimensions	Center of piping	J J Center of piping	J Center of piping


Model	Standard specifications											
woder	P1	P2	Α	B Note 1)	С	D	F	J	К			
<sup>10</sup> -ARP20(K)	1/8, 1/4	1/8	40	98	27	28.5	M28 x 1	28.5	2 Note 2)			
<sup>10</sup> <sub>21</sub> - ARP30(K)	1/4, 3/8	1/8	53	117	29	29.5	M38 x 1.5	29.5	2.5			
<sup>10</sup> <sub>21</sub> - ARP40(K)	1/4, 3/8, 1/2	1/4	70	148	41	34	M42 x 1.5	34	1			

	Optional specificatio							cations							
Model	Dig pressur	ital e switch	Roun pressure g	d type auge <sup>Note 3)</sup>	e Bracket mount dimension Panel mou					Bracket mount dimension				mount	
	н	J	н	J	М	N	Q	R	S	Т	U	v	w	Y	Z
<sup>10</sup> <sub>21</sub> - ARP20(K)	□27.8	40	ø44	69	30	34	47	5.4	15.4	55	2.3	28	28.5	14	6
<sup>10</sup> / <sub>21</sub> - ARP30(K)	□27.8	41	ø44	70	41	40	44	6.5	8	53	2.3	31	38.5	19	7
<sup>10</sup> -ARP40(K)	□27.8	45	ø44	74	50	54	54	8.5	10.5	70	2.3	35.5	42.5	21	7

Note 1) The total length of B direction is the length when the filter regulator knob is unlocked. Note 2) For:<sup>2</sup> ARP20(K) only, the position of pressure gauge is above the center of the piping. Note 3) For dimensions of round-type pressure gauge for special application, please contact SMC.



# Options ( E CRU us Digital Pressure Switch RoHS




Note 2) Unit name plate is attached. Note 3) Operation manual is included.

Note 4) When ordering the body only, select the symbol from 1 to 3 respectively.

### Specifications

alions					
ressure range		0 to 1 MPa			
sure range		-0.1 to 1 MPa			
nd pressure		1.5 MPa			
sure resolution	1	0.01 MPa			
upply voltage		12 to 24 VDC, Ripple (p-p) 10% or less (with power supply polarity protection)			
consumption		55 mA or less (at no load)			
output		NPN or PNP open collector 1 output			
Maximum load current		80 mA			
Maximum applied voltage		30 V (at NPN output)			
Residual voltage		1 V or less (with load current of 80 mA)			
Response time		1 s			
Anti-chattering function		(0.25, 0.5, 2, 3)			
Short-circuit p	rotection	Yes			
bility		±1% F.S. or less			
Hysteresis m	ode	Variable (0 or above)			
Window comp	arator mode	Vallable (0 01 above)			
Display		3-digit, 7-segment indicator, 2-color display (Red/Green) can be interlocked with the switch output.			
Display accuracy		±2% F.S.±1 digit (25°C ±3°C)			
r light		Light up when output is turned ON. (Green)			
nent resistance	Enclosure	IP40			
re with connect	or	ø3.4 3-wire 25AWG 2 m			
	sure range d pressure sure resolution upply voltage consumption nutput Maximum loac Maximum app Residual volta Response tim Anti-chattering Short-circuit p bility Hysteresis m Window comp accuracy r light hent resistance	sure range did pressure sure resolution upply voltage consumption utput Maximum load current Maximum applied voltage Residual voltage Residual voltage Response time Anti-chattering function Short-circuit protection bility Hysteresis mode Window comparator mode accuracy r light			

**SMC** 





# Series <sup>10</sup>/<sub>21</sub> ARP20/30/40 Series <sup>10</sup>/<sub>21</sub> ARP20K/30K/40K Specific Product Precautions 1

Be sure to read this before handling. Refer to page 1382 for Safety Instructions.

Design

# **M**Warning

- Be sure to install a safety device to prevent damage or malfunction of the outlet side components when the output pressure exceeds the set pressure value.
- Please consult with SMC if the intended application calls for absolutely zero leakage due to special atmospheric requirements, or if the use of a fluid other than air is required.

# **A**Caution

- 1. Select a model that is suitable for the desired cleanliness by referring to the SMC's Best Pneumatics catalog.
- 2. Components cannot be used for applications that are outside the range of specifications.

Please consult with SMC when you anticipate using the component outside the range of its specifications (such as temperature and pressure).

 Even when the product is used in the specified range, it may chatter depending on the operating conditions. Please contact SMC for the details of this chattering.

Selection

# **M**Warning

- 1. The mineral grease used on internal sliding parts and seals may run down to outlet side components. Please consult with SMC if this is not desirable.
- 2. Residual pressure release (outlet pressure release) is not complete by releasing the inlet pressure. To release residual pressure, select a model with a backflow function. Using a model without a backflow function makes for inconsistent residual pressure release (i.e., residual pressure may or may not be released) depending upon the operating conditions.
- 3. Please contact SMC if air will not be consumed in the system for a long period of time, or if the outlet side will be used with a sealed circuit and a balanced circuit, as this may cause the set pressure of the outlet side to fluctuate.
- 4. Set the regulating pressure range for the outlet pressure of the regulator in a range that is 90% or less of the inlet pressure.

If set to above 90%, the outlet pressure will be easily affected by fluctuations in the flow rate and inlet pressure, and become unstable.

5. A safety margin is calculated into the maximum regulating pressure range appearing in the catalog's specification table.

However, the outlet pressure may exceed the set pressure due to a delay in the valve's closing.

6. Please contact SMC when a circuit requires the use of a regulator having relief sensitivity with high precision and setting accuracy. Mounting

### **≜**Caution

- To avoid reversed connections of the air inlet/outlet, make connections after confirming the "IN/OUT" mark or arrows that indicate the direction of air flow. Reversed connections can cause malfunction.
- Leave a space of 100 mm or more for maintenance on the valve guide side (opposite side from the knob).
- 3. When the product is installed between a solenoid valve and an actuator, select a backflow function type.

Adjustment

### A Warning

- Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges.
   Turning the knob excessively can cause damage to the internal parts.
- Do not use a tool on the pressure regulator knob as this can cause damage. It must be operated manually.

# ▲Caution

- 1. Be sure to check the inlet pressure before setting the outlet pressure.
- 2. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure.

Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.

- Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
- Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).



3. To set the pressure using the knob, turn the knob in the direction that increases pressure and lock the knob after the pressure is set.

If this is done in the direction that decreases pressure, the pressure may drop from the original set pressure. Turning the knob clockwise increases the outlet pressure, and turning it counterclockwise reduces the pressure.

4. Do not apply pressure exceeding the range of specifications.

It can damage the pressure gauge.





# Series <sup>10</sup>/<sub>21</sub> ARP20/30/40 Series <sup>10</sup>/<sub>21</sub> ARP20K/30K/40K Specific Product Precautions 2

[N.m]

ÌSMC

Be sure to read this before handling. Refer to page 1382 for Safety Instructions.

Adjustment

# **∆**Caution

5. The product consumes a small amount of fluid from the bleed port.

The product is designed to have a bleed mechanism for highly accurate pressure adjustment, and consumes a small amount of fluid from the bleed port. This should not be considered abnormal.

Air Supply

## ▲Warning

1. Use a mist separator on the inlet side of the product.

If the supplied air contains condensate or dust, the bleed mechanism can malfunction.

2. Do not use a lubricator on the inlet side of the product, as the bleed mechanism can malfunction.

Piping

### **A** Warning

1. To screw piping materials into components, tighten with a recommended tightening torque while holding the female thread side.

If the minimum tightening torque is not observed, this can cause a looseness and seal failure. On the other hand, excess tightening torque can cause damage to the threads. Furthermore, tightening without holding the female thread side can cause damage due to the excess force that is applied directly to the piping bracket.

### **Recommended Tightening Torque**

Connection thread	1/8	1/4	3/8	1/2
Torque	7 to 9	12 to 14	22 to 24	28 to 30

- Avoid excessive torsional moment or bending moment other than those caused by the equipment's own weight as this can cause damage. Support external piping separately.
- 3. Piping materials without flexibility such as steel tube piping are prone to be affected by excess moment load and vibration from the piping side. Use flexible tubing in between to avoid such an effect.

Maintenance

### **∕** Marning

- When disassembly or installation is required during the maintenance, repair, or replacement of a device, be sure to follow the instructions provided in the operation manual or safety instructions in this catalog.
- 2. When using the regulator with backflow function between a solenoid valve and an actuator, check the pressure gauge periodically.

Sudden pressure fluctuations may shorten the durability of the pressure gauge. A digital pressure gauge is recommended for such situation or as deemed necessary.

# A Caution

1. For emergency action in the event of setting failure or leakage from the relief port, refer to "Troubleshooting" in the Operation Manual of the product.



Directional Control Valves

Cylinders

Air

**Rotary Actuators** 

Grippers

Air

Pressure Switches/ Pressure Sensors